



## Mounting Instructions



## **TILTINDICATOR '3in1'** Placement

Place the TiltIndicator '3in1' in upright position at a bottom corner for left/right tilt detection.

To also monitor front/back tilting: place a 2nd device on an adjacent side.





- Keep the TiltIndicator '3in1' **upright** during and after removal of the backliner, as from that point on it is armed and ready to activate.
- Stick the indicator firmly on the parcel.





- Write the unacceptable degree/angle of tilting on the instruction label.
- Place that close to the indicator on the parcel.





- Stick the alert sticker on your bill of lading.

For additional product information, please visit www.TiltIndicator.eu